

NOTES:

- Refer to the Element Prescriptive Engineering for reinforcement design of Element ICF walls.
- Treating the soil ahead of time is another method of avoiding termite related problems.
- Please refer to local building codes for more information on termite control.
- Recommend gluing in place Height Adjusters with foam adhesive.



©Copyright Logix Brands Ltd. (2024) All ©Lopyright Logik Brands Ltd. (2024) All rights reserved. No part of the work contained herein as covered by this copyright may be reproduced or used in any form, or any means - graphic, electronic or mechanical, including without

By using these drawings, you agree to assume all risks associated therewith. See Logixbrands.com/Disclaimer-Drawings for full copy of disclaimer.

Drawing:

5.11.1.4

Date:

Mar 03/23

1/1

Title:

TERMITE INSPECTION STRIP

ElementICF.com A Product By Logix Brands Ltd. 1-866-944-0153