

NOTES:

- 1. Refer to the Element Prescriptive Engineering for reinforcement design of Element ICF walls.
- 2. A protective cover, such as tarp, should be placed over Element form panels in the vicinity where on-site welding or torch work is conducted.

