



NOTES:

1. Install vertical rebar 6 inches beyond corbel width for full height of wall each face.
2. Reinforcement details should be reviewed by a local licensed professional engineer.



©Copyright Logix Brands Ltd. (2024) All rights reserved. No part of the work contained herein as covered by this copyright may be reproduced or used in any form, or any means - graphic, electronic or mechanical, including without limitation photocopying.

By using these drawings, you agree to assume all risks associated therewith. See Logixbrands.com/Disclaimer-Drawings for a full copy of disclaimer.

Drawing:
5.17.4.2

Date:
Mar 03/23

Pg:
1/1

Title:
CORBEL SUPPORTING TIMBER POST