



**NOTES:**

1. Refer to the Element Prescriptive Engineering for reinforcement design.
2. Refer to the Element Installation Guide for more information on Simpson Strong Tie ledger connectors.
3. Drawing shows bottom course of Element with bottom Interlocks removed. Optionally, leaving bottom interlocks along the bottom course will increase wall height by 0.525"



©Copyright Logix Brands Ltd. (2024) All rights reserved. No part of the work contained herein as covered by this copyright may be reproduced or used in any form, or any means - graphic, electronic or mechanical, including without limitation photocopying.

By using these drawings, you agree to assume all risks associated therewith. See [Logixbrands.com/Disclaimer-Drawings](https://Logixbrands.com/Disclaimer-Drawings) for a full copy of disclaimer.

Drawing:  
5.5.1.4

Date:  
Mar 03/23

Pg:  
1/1

Title:  
ELEMENT 6 in CRAWL SPACE TO  
ELEMENT 4 in ABOVE-GRADE